

# CHARCOAL GRILL INSTRUCTIONS

Remove grill grate from grill, and pile charcoal for lighting. Once charcoal is ready for cooking, spread it out evenly with a garden rake.

Replace grill grate and put in its highest position, you can lower it as needed. Never put heavy pots on grill.

Remove grill grate and let it cool before cleaning. Do not douse hot coals with water while they are in grill; this may warp the grill. Let grill cool on its own.

# GAS GRILL INSTRUCTIONS

Using a long lighter put the lit lighter down in the grill and turn on corresponding knob or gas valve.

Light all desired burners in the same manner.

Let cool for 20 minutes and wire brush the grill grates, being careful not to drop and do not clean cast iron grates with water.